

SINGLE-ROOM REVERSIBLE ENERGY REGENERATION VENTILATOR



Vento Expert A30 W V.2

EN

USER'S MANUAL



BLAUBERG
Ventilatoren

CONTENTS

Safety requirements.....	3
Purpose.....	5
Delivery set.....	5
Designation key.....	5
Technical data.....	6
Design and functioning.....	7
Mounting and set-up.....	8
Connection to power mains.....	11
Technical maintenance.....	22
Storage and transportation regulations.....	23
Manufacturer's warranty.....	24
Certificate of acceptance.....	27
Seller information.....	27
Installation certificate.....	27
Warranty card.....	27

This user's manual is a main operating document intended for technical, maintenance, and operating staff.

The manual contains information about purpose, technical details, operating principle, design, and installation of the Vento Expert A30WV.2 unit and all its modifications.

Technical and maintenance staff must have theoretical and practical training in the field of ventilation systems and should be able to work in accordance with workplace safety rules as well as construction norms and standards applicable in the territory of the country.

The information in this user's manual is correct at the time of the document's preparation.

The Company reserves the right to modify the technical characteristics, design, or configuration of its products at any time in order to incorporate the latest technological developments.

No part of this publication may be reproduced, stored in a retrieval system, or transmitted, in any form or by any means in any information search system or translated into any language in any form without the prior written permission of the Company.

SAFETY REQUIREMENTS

- Please read the user's manual carefully prior to installing and operating the unit.
- All user's manual requirements as well as the provisions of all the applicable local and national construction, electrical, and technical norms and standards must be observed when installing and operating the unit.
- The warnings contained in the user's manual must be considered most seriously since they contain vital personal safety information.
- Failure to follow the rules and safety precautions noted in this user's manual may result in an injury or unit damage.
- After a careful reading of the manual, keep it for the entire service life of the unit.
- While transferring the unit control, the user's manual must be turned over to the receiving operator.

UNIT INSTALLATION AND OPERATION SAFETY PRECAUTIONS



- Disconnect the unit from power mains prior to any installation operations.



- Unpack the unit with care.



- The unit must be grounded!




- While installing the unit, follow the safety regulations specific to the use of electric tools.




- Do not change the power cable length at your own discretion.
- Do not bend the power cable.
- Avoid damaging the power cable.
- Do not put any foreign objects on the power cable.



- Do not lay the power cable of the unit in close proximity to heating equipment.



- Do not use damaged equipment or cables when connecting the unit to power mains.



- Do not operate the unit outside the temperature range stated in the user's manual.
- Do not operate the unit in aggressive or explosive environments.




- Do not touch the unit controls with wet hands.
- Do not carry out the installation and maintenance operations with wet hands.



- Do not allow children to operate the unit.




- Do not store any explosive or highly flammable substances in close proximity to the unit.



- Do not open the unit during operation.



- Do not block the air duct when the unit is switched on.



- Do not sit on the unit and avoid placing foreign objects on it.



- Do not wash the unit with water.
- Protect the electric parts of the unit against ingress of water.



- Disconnect the unit from power mains prior to any technical maintenance.



- When the unit generates unusual sounds, odour, or emits smoke, disconnect it from power supply and contact the Seller.



- Do not direct the air flow produced by the unit towards open flame or ignition sources.



- In case of continuous operation of the unit, periodically check the security of mounting.



- Use the unit only for its intended purpose.



**THE PRODUCT MUST BE DISPOSED SEPARATELY AT THE END OF ITS SERVICE LIFE.
DO NOT DISPOSE THE UNIT AS UNSORTED DOMESTIC WASTE.**

PURPOSE

The ventilator is designed to ensure continuous mechanical air exchange in flats, cottages, hotels, cafés and other domestic and public premises. The ventilator is equipped with a regenerator that enables supply of fresh filtered air heated by means of extract air heat energy recovery. The ventilator is designed for wall flush mounting.

The unit is rated for continuous operation without disconnection from the power supply.



THE UNIT SHOULD NOT BE OPERATED BY CHILDREN OR PERSONS WITH REDUCED PHYSICAL, MENTAL, OR SENSORY CAPACITIES, OR THOSE WITHOUT THE APPROPRIATE TRAINING.

THE UNIT MUST BE INSTALLED AND CONNECTED ONLY BY PROPERLY QUALIFIED PERSONNEL AFTER THE APPROPRIATE BRIEFING.

THE CHOICE OF UNIT INSTALLATION LOCATION MUST PREVENT UNAUTHORIZED ACCESS BY UNATTENDED CHILDREN.


Transported air must not contain any flammable or explosive mixtures, evaporation of chemicals, sticky substances, fibrous materials, coarse dust, soot and oil particles or environments favourable for the formation of hazardous substances (toxic substances, dust, pathogenic germs).

DELIVERY SET

Name	Quantity
Indoor unit	1 pc.
Air duct	1 pc.
Sound absorbing mat	1 pc.
Assembled cartridge	1 pc.
Outer ventilation hood	1 pc.
Cardboard mounting template	2 pcs.
Fastening kit	2 sets
Polystyrene wedges	1 set
User's manual	1 pc.
Installation instruction for the ventilation hood	1 pc.
Packing box	1 pc.

DESIGNATION KEY

Vento Expert A 30 L1.0 S10 W V.2



* Minimum wall thickness for the unit with a mounting frame

TECHNICAL DATA

The unit is designed for indoor application at outdoor air temperatures from -15 °C up to +40°C and relative indoor humidity up to 50 %.

The unit has Class II of protection against electric shock and must not be grounded.

Hazardous parts access and water ingress protection rating is IP24.


The unit design is constantly being improved, so some models may be slightly different from those ones described in this manual.

TECHNICAL DATA

Speed	I	II	III
Power supply voltage 50 (60) Hz [V]	1~100-240		
Power consumption [W]	1.8	3.0	4.40
Current consumption [A]	0.027	0.037	0.051
Max. air flow [m ³ /h] (CFM)	10 (6)	20 (12)	30 (18)
Filters	G3 (MERV 7);		
Sound pressure level @ 1 m [dBA(Sones)]	30 (1.1)	37 (2.0)	40 (2.5)
Sound pressure level @ 3 m [dBA(Sones)]	21 (0.4)	28 (0.9)	31 (1.1)
Outdoor noise level attenuation [dBA (Sones)]	42 (2.5)		
IP rating	IP24		

WI-FI TECHNICAL DATA

Standard	IEEE 802.11 b/g/n
Frequency band [GHz]	2.4
Transmission power [mW] (dBm)	100 (+20)
Power mains	DHCP
WLAN safety	WPA, WPA2




The air duct length depends on the ventilator model, refer to the Designation Key, page 5.

The supplied ventilation hood model depends on the ventilator model.

The distance A and overall dimensions of the outer ventilation hood are stated in the installation instruction for the ventilation hood.

The overall dimensions of the front panel are stated below.

OVERALL DIMENSIONS OF THE INDOOR UNIT [MM]




DESIGN AND FUNCTIONING

The ventilator consists of an indoor unit with a decorative front panel, a cartridge, an air duct with a sound absorbing mat and an outer ventilation hood.

Cartridge is the basic functioning part of the ventilator. The cartridge consists of a fan, a regenerator and two filters that ensure rough air filtration and prevent ingress of dust and foreign objects into the regenerator and the fan.

The indoor unit is equipped with an automatic air damper that closes during shutdown of the ventilator and prevents air backdraft.

VENTILATOR DESIGN



VENTILATOR OPERATION MODES

The ventilator has three operation modes:

Ventilation: the ventilator runs either in extract or supply mode at a set speed.

Air supply (available from a mobile device only): all the connected ventilators in the network go to the air supply mode.

Regeneration: the ventilator runs in the reversible mode with heat and humidity recovery.


In the **Regeneration** mode the ventilator operates in two cycles.

Cycle I. Warm stale extract air flows through the ceramic regenerator and heats it up and moisturizes the regenerator.


Cycle II. Fresh and cold intake air from outside flows through the ceramic regenerator, absorbs accumulated moisture and get heated up to the room temperature with the heat accumulated in the heat exchanger.

FUNCTIONING OF AUTOMATIC AIR DAMPER

The cover is closed



The cover is open



The indoor unit has a front panel with automatic air damper. During the ventilator operation the air damper opens to let the air flow through the ventilator.

After turning off the ventilator, close the air damper by hand to prevent drafts.

MOUNTING AND SET-UP




READ THE USER'S MANUAL BEFORE INSTALLING THE UNIT.




DO NOT BLOCK THE AIR DUCT OF THE INSTALLED VENTILATOR WITH DUST ACCUMULATING MATERIALS, SUCH AS CURTAINS, CLOTH SHUTTERS, ETC. AS IT PREVENTS AIR CIRCULATION IN THE ROOM.

1. Prepare a round core hole in the outer wall. The hole size is shown in the figure below.







2. Insert the air duct in the wall hole. For ease of installation use the polystyrene wedges included in the delivery set. The air duct end must protrude for the distance A that enables installation of the outer ventilation hood. The distance A is stated in the installation instruction for the ventilation hood.



Install the air duct with the minimum slope of 3 mm downwards to the outer wall side.




To cut the air duct, either make preliminary calculations of the required duct length or make sure to have access to the outer wall after fixation of the air duct.

3. Take the required mounting template and then fasten it to the indoor wall using the adhesive tape. The large opening in the template must be coaxial with the air duct. For aligning the template with respect to the horizon line it is recommended to use a builder's level. Then mark the fastening holes for installation of the supplied dowels and drill the holes to a required depth. Route the power cable of the ventilator from the wall through the marked opening on the template.



4. Pull the lug on the bottom to disconnect the front panel of the indoor unit from the rear part. Attach the mounting frame on the wall if you use it.


Fix the rear part of the indoor unit on the wall or on the mounting frame using the screws supplied with the mounting kit of the ventilator.




5. Remove the two screws that retain the terminal cover to enable access to the connection terminals.

Route the power cable as figured below and connect the ventilator to power mains in compliance with the external wiring diagram, see page 11.

Fix the power cable and the control cables with a cable clamp. After completion of the electrical connection re-install the transparent terminal cover in site.



6. Insert the cartridge into the air duct and insert the plug cartridge to the controller. Re-install the front panel of the indoor unit rear part.



CONNECTION TO POWER MAINS

POWER OFF THE POWER SUPPLY PRIOR TO ANY OPERATIONS WITH THE UNIT. THE UNIT MUST BE CONNECTED TO POWER SUPPLY BY A QUALIFIED ELECTRICIAN. THE RATED ELECTRICAL PARAMETERS OF THE UNIT ARE GIVEN ON THE MANUFACTURER'S LABEL.

ANY TAMPERING WITH THE INTERNAL CONNECTIONS IS PROHIBITED AND WILL VOID THE WARRANTY.

The ventilator is rated for connection to single-phase AC 100 – 240 V 50/60 Hz power mains. The installation of power cables is described in the Installation and set-up section.


Connect the unit to power mains using durable, insulated and heat-resistant conductors (cables and wires). The total minimum cross section for the power cable must be 0.5 up to 0.75 mm². The actual wire cross section selection must be based on the maximum load current, maximum conductor temperature depending in the wire type, insulation, length and installation method.

Use copper wires for all the electric connections!

Connect the unit to power mains via the terminal block in compliance with the wiring diagram and terminal designation. Connect the ventilator to power supply through an automatic circuit breaker with electromagnetic trip integrated into the home wiring system. The rated trip current of the automatic circuit breaker or the safety fuses must exceed the maximum current consumption of the unit, refer to the Technical data section.

The recommended trip current of the circuit breaker or safety fuse is the next current in the standard trip current row following the maximum current of the connected unit.


WIRING DIAGRAM



VENTILATOR SET-UP









Prior to operating the ventilator set it up using the DIP switch. It is located on the controller circuit board.

To access the DIP switch, take off the front panel of the indoor unit.



To reset the ventilator to the factory settings, keep the reset button under the front panel pressed for 5 seconds till a long beep. Reset to the factory settings is also possible via the mobile application.





POSITIONING OF THE DIP SWITCH

Setup of ventilator operation mode	
 1	OFF: Master unit.
 1	ON: Slave unit.
Standby mode setup	
 2	OFF: shutdown of the ventilator in the Standby mode.
 2	ON: the ventilator is running at the first speed in the Standby mode.
Ventilation mode setup	
 3	OFF: the ventilator runs in the extract mode.
 3	ON: the ventilator runs in the supply mode.
Programming mode	
 4	OFF: standard operation mode.
 4	ON: programming mode.
Warning! The programming mode can be switched by the service engineers only!	






VENTILATOR CONTROL

The ventilator is operated with the following controls:

- the buttons located on the side of the indoor unit (see the figure below)
- the mobile application Blauberg Vento V.2 installed on a smartphone or a tablet
- The Smart home application. The ventilators must be connected to the Smart home application in compliance with user's manual for this application.

	•	On/Off
	III • II • I •	Speed The speed selection sequence is follows: low-medium-high.
	• F • A •	Regeneration The ventilator runs in the reversible mode with heat and humidity recovery.
	• M •	Ventilation The ventilator runs in the supply or extract mode with the set speed.

VENTILATOR CONTROL WITH THE BUTTONS ON THE INDOOR UNIT

	<p>On/Off</p>
	<p>The speed selection sequence is follows: low-medium-high. The speed of all the interconnected ventilators in the network is set with the Master unit. I: permanent glowing of the indicator indicates running of the ventilator at the low speed. Blinking of the indicator indicates activation of the timer Night mode. I and II: permanent glowing of the indicators I and II indicates running of the ventilator at the medium speed. I, II and III: permanent glowing of the indicators I, II and III indicates running of the ventilator at the high speed. Synchronous blinking of the indicators I, II and III indicates activation of the timer in the Party mode or the turn-off delay timer in the Boost mode in case of triggering of the integrated humidity sensor or the connected external relay sensor. Alternate blinking of the indicators I, II and III indicates running of the ventilator at the speed set with the mobile application using the slider selector for manual speed setting or activation of the scheduler.</p>
	<p>Regeneration mode Rotation direction of the fan is changed. Heat regeneration is accomplished in the Regeneration mode. To enable operation of the ventilators in opposite direction change the position of the DIP switch No. 3.</p>
<p>F</p>	<p>Filter clogging indicator. The indicator starts blinking 90 days after installation of the cartridge. In this case clean or replace the filters (see the «Technical maintenance» section).</p> <p>After replacement of the filters reset the filter timer using the mobile application or press and hold the  button on the indoor unit of the Master unit for 5 seconds, until a signal beeps.</p>
<p>A</p>	<p>Alarm indicator. In case of a failure the Alarm indicator on the indoor unit starts to glow or to blink.</p> <p><u>Reasons for glowing of the indicator:</u></p> <ul style="list-style-type: none"> Alarm shutdown of a ventilator caused by another defective ventilator in the network. <p><u>Reasons of alarm blinking:</u></p> <ul style="list-style-type: none"> Battery charge is below the allowable limit No connection between the Master unit and the router Alarm shutdown of a ventilator. This ventilator causes shutdown of all interconnected ventilators in the network. <p>In case of communication loss of the Master unit with the router longer than 20 seconds, the Master unit goes to the Standby mode and the Slave units signal of communication loss with the Master unit. After resumption of the connection the Slave units automatically get synchronized with the Master unit.</p>
	<p>Ventilation mode The ventilator operates in the supply or extract mode with the set speed. The fan rotation direction depends on the position of the DIP switch 3.</p>
<p>No glowing of the indicators «Regeneration» and «Ventilation» indicates activated supply ventilation mode of the ventilator.</p>	
<p>M</p>	<p>Permanent glowing of the indicator identifies the Master unit in the network. The blinking Indicator identifies the Slave unit in the network and no connection with the Master unit. No glowing of the indicator identifies the Slave unit connected with the Master unit.</p>
<p>Synchronous blinking of all the indicators on the ventilator casing indicates the activated Setup mode.</p>	

VENTILATOR CONTROL WITH MOBILE APPLICATION

To enable ventilator control with a mobile device install the Blauberg Vento V.2 application.

[Blauberg Vento V.2 - App Store](#)

[Blauberg Vento V.2 Play Market](#)




Your mobile device must have the operation system matching the following parameters:

- iOS – iOS: 8 or later. Compatible with iPhone, iPad, iPod.
- Android – Android: 4 or later.

CONNECTION OF MOBILE APPLICATION TO THE VENTILATOR


Download the Blauberg Vento V.2 application and install it on the mobile device.

If there is no connection with the ventilator during launching of the application the mobile device displays the following message:



By default, the ventilator operates as a Wi-Fi access point. Connect the mobile device to the Wi-Fi access point with the name (FAN: + 16 ID Number characters) stated on the ventilator casing under the front panel.

Wi-Fi access point password: 11111111.



Enter the Blauberg Vento V.2 app and create a new connection as follows:











1. Enter the app menu.
2. Select **Connection - At home**.
3. If mobile device is connected to the Wi-Fi access point without router, select the **default** connection.
4. In case of connection via router start searching for ventilators in the network.
5. Find the new connection in the list and highlight its ID.
6. Edit the connection details.
7. If necessary, re-name the connection and enter the ventilator password. By default the ventilator password is 1111 (is highlighted in the entry line automatically). The password 1111 is a default password for the ventilator.

WARNING! At this stage the password for the ventilator cannot be changed.






8. Confirm the entered data.

Once the connection has been established, go to the app menu and choose **Control**.

DESCRIPTION OF MOBILE APPLICATION CONTROL BUTTONS

	ON/Standby. The Standby mode is determined by the DIP switch No. 2 position (see page 11).	
	Selection of the pre-set speed: low, medium and high speed respectively.	
	Manual speed setting. Check the scroll bar * to activate it.	
	Ventilation. The ventilator operates either in the extract or supply mode at the set speed. The air direction is determined by the DIP switch No. 3 position (see page 11).	
	Regeneration. The fan rotation direction changes to opposite each 70 seconds. This operation mode enables heat recovery.	
	Air supply. The ventilator operates exclusively in supply mode.	
	Night mode. Activation of the low speed timer (the default setting is 8 hours, adjustable in the menu Settings-Timers).	
	Scheduler. Activation of the week scheduled operation.	
	Party mode. Activation of the high speed timer (4 hours by default, adjustable in the menu Settings-Timers).	

DESCRIPTION OF MOBILE APPLICATION INDICATORS

	Current type of connection to the ventilator. Home connection or connection via a cloud server through Internet respectively.
boost	Maximum speed activation indicator. It goes on after actuation of the humidity or any other connected external relay sensor. When this mode is active, all the other modes are disabled. After air humidity decrease or disappearance of signal from an external relay sensor after countdown of the turn-off delay timer (default setting 30 minutes) the ventilator reverts to the previous mode. Press the Power button to deactivate this operation mode.
	Filter replacement indicator. To reset the filter timer, go to Menu- Settings-Filter .
	Alarm indicator. The indicator glows in case of alarm and it has two colours. The indicator glows red in case of alarm shutdown of the ventilator. The indicator glows orange if battery is not available or the battery charge is low.
	Humidity indicator. It glows if the indoor humidity is above the set point.
	External relay sensor indicator. It glows, if the sensor is actuated.

When simultaneously activating several operation modes that exclude each other, the operation mode selection is done according to the following priority:

1. **Night mode** timer or **Party mode** timer.
2. **Standby**.
3. **Boost**.
4. **Scheduler**.
5. Regular mode.

VENTILATOR PASSWORD CHANGE

To change the ventilator password in the mobile application, go to **Menu-Connection-At home**.

1. Select the connection type and press the **Settings** button.
2. Enter and confirm the password.
3. Press the **Change Password** button.




TIMER SETUP

To set the **Night mode**, **Party mode** timer and the turn-off delay timer for the **Boost** mode, go to **Menu-Settings-Timers** in the mobile application.

The **Night mode timer** defines switch delay to the low speed after activation of the **Night mode** (8 hours by default).

The **Party timer** defines switch delay to the high speed after activation of the **Party mode** (4 hours by default).

The **turn-off delay timer for the Boost mode** defines switch delay to the high speed after triggering of any sensor and reset of the sensor to the standard status.




SENSOR SETUP

To set up sensor operation via the mobile application, go to **Menu-Settings-Sensors**.

Humidity sensor: actuation of the humidity sensor. When the indoor humidity exceeds the set point, the ventilator goes to the high speed. When the indoor humidity drops down below the set point, the turn-off delay timer for the **Boost mode** is activated. After the delay timer countdown, the ventilator reverts to the previous speed setting. After the ventilator operation in the Boost mode comes to the end, the ventilator reverts to the previous speed setting.

Relay sensor: triggering of the external relay sensor. As the NO contact of the external relay sensor is closed, the ventilator goes to the high speed. As the NO contact opens, the turn-off delay timer for the «Boost» mode is activated. After the ventilator operation in the Boost mode comes to the end, the ventilator reverts to the previous speed setting.

This ventilator model can't be connected to **0-10 V sensor**, so setup of this sensor is disabled.




DATE AND TIME SETUP

To set up the ventilator date and time, go to **Setting–Date and time**.

Current time: set the current time.

Current date: set the current date.



WEEKLY SCHEDULE SETUP

To set up the weekly schedule in the mobile application, go to **Menu–Settings–Scheduler**.


The weekly schedule can be set by means of 4 time intervals available for each day of the week.

You can select one of the three fan speeds or **Standby** for each time interval.


To receive the current settings for the selected day of the week, press the **Receive** button.

To apply the selected settings for the selected day of the week, press the **Apply** button.

For proper operation of the week scheduler check the settings for the date and time.



FILTER TIMER RESET


The ventilator filters must be serviced after every 90 hours of continuous operation. The need to replace the filters is communicated by the indicator  in the upper section of the **Control** menu. Replace the filter and reset the filter timer.

To reset the filter timer via the mobile application go to **Menu–Settings–Filter**. Then press the **Reset filter timer** button.

The 90 days are counted on the master ventilator only.

The filter replacement indication is replicated on all the Slave units. In this case, replace the filters on all the ventilators in the network. After filter timer reset the filter replacement indicator goes off on all the connected ventilators.

The filter timer can also be reset by means of the button on the indoor unit (see page 13).




RESET TO FACTORY SETTINGS

To reset to the factory settings via the mobile application, go to **Menu–Setting–Factory settings**. Then press the **Reset to factory settings** button.

WARNING!

Reset to the factory settings may result in losing Wi-Fi connection with the device.



WIRELESS CONNECTION OF SEVERAL VENTILATORS

The ventilator has two operation modes.

Master unit (Master). The ventilator acts as a Master unit. The **Slave** units and the mobile devices are connected to the **Master** unit via the Wi-Fi connection. The Master unit is controlled via the mobile application or the sensor buttons on the ventilator casing. The control signal is automatically transmitted to all the **Slave** units in the network. In this mode the ventilator responds to signal from the sensors and goes to a respective operation mode.

Slave unit (Slave). The unit acts as a Slave unit in the network. The ventilator responds to the control signals from the **Master** unit only. Any other signals from other controls are ignored. In this mode the ventilator does not respond to the signals from the sensors. In case of communication loss with the Master unit longer than 20 seconds, the ventilator goes to the **Standby** mode.

WI-FI PARAMETER SETUP

Setup of the Wi-Fi parameters is only possible on Master units. To set up ventilator Wi-Fi parameters via the mobile app, go to **Menu–Connection–Wi-Fi setup**.

Press the **Receive** button to display the current Wi-Fi settings.

Select one of the Wi-Fi operation modes:

Access point: access point mode without a home router.

Select the desired security level for the **Access point** mode:

- **Open:** open Wi-Fi network, not protected with password.
- **WPA PSK:** password-protected. The encryption technology based on the WPA protocol does not ensure full security.
- **WPA2 PSK:** password-protected. The encryption technology is for modern networks.
- **WPA/WPA2 PSK:** password-protected (recommended). This combined technology activates WPA and WPA2 and provides compatibility with any electronic devices.

Enter your access point password and press the **Apply** button.

Client: client mode. The ventilator operates in the home router network.

Enter the home router details and the IP address type for the client mode.

Enter the name of the Wi-Fi home router access point.

Enter the password for the Wi-Fi home router access point.

Select IP address type:

DHCP: the IP address is set up automatically upon connection to the home router (recommended).

Static: enables manual entry of the desired IP address, subnet mask and default gateway. These settings are recommended for expert users only. Select this IP address type at your own risk.

Then press the **Apply** button.


The screenshot shows the 'Wi-Fi setup' screen with 'Access point' mode selected. Under 'Security modes', 'WPA/WPA2 PSK' is chosen. The 'Wi-Fi password' field is empty with a hint '8 - 64 characters'. The 'Wi-Fi channel' is set to '11'. At the bottom, there are 'Receive' and 'Apply' buttons.

The screenshot shows the 'Wi-Fi setup' screen with 'Client' mode selected. Under 'Wi-Fi name', the field is empty with a hint '1 - 32 characters'. The 'Wi-Fi password' field is empty with a hint '0 - 64 characters'. Under 'Type of IP address', 'DHCP' is selected. At the bottom, there are 'Receive' and 'Apply' buttons.

VENTILATOR WIRELESS CONNECTION DIAGRAMS


Wiring diagram 1

Connection of up to 8 **Slave** units or mobile devices to the **Master** unit with its own wireless access point.




Wiring diagram 2

The **Master** units, the **Slave** units and the mobile devices are connected to a Wi-Fi access point of the router. In this case, the **Master** unit can operate with the number (N) of **Slave** units, limited by the technical characteristics of the router.



If the Wi-Fi router capacity is not enough to connect a required number of the ventilators, you may use an extra wireless access point to connect the other units. Optionally connection of several **Master** units to the network for arranging a zone control is also possible.



CONNECTING MASTER AND SLAVE VENTILATORS





WHILE COMPLETING THE CONNECTION MAKE SURE THAT THE SLAVE UNITS ARE WITHIN COVERAGE OF THE BUILT-IN WI-FI IN THE MASTER UNIT

To connect a Master and a Slave unit, set the DIP switches on each ventilator to set it as a Master or the Slave unit (see page 12). Then set up the Wi-Fi parameters of the master unit (see page 18).





AFTER CHANGING THE WI-FI PARAMETERS OF THE MASTER VENTILATOR REPEAT THE CONNECTION STEPS!

Press and hold the **Ventilation**  button on the Master unit casing. Wait for the beep and the blinking of all the LED lights on the unit casing. Repeat the steps with all the Slave units and wait for the beep when all the LED lights stop blinking on each Slave unit. Set the Master unit to the normal operation mode. Press and hold the **Ventilation**  button. Wait for the beep and going down of all the LED lights.

Note: If the home router works in conjunction with several Wi-Fi access points and the ventilators require connection to different access points:

- Connect the Master unit to the first Wi-Fi access point.
- Complete the connection with the first group of Slave units.
- Connect the Master unit to the second Wi-Fi access point.
- Complete the connection with the second group of Slave units.


SPECIAL SETUP MODE

In the event of losing the Wi-Fi password or the Master unit password or in other cases use the recovery Setup mode to restore access to the ventilator functions. To enter the special setup mode, press and hold the **Ventilation**  button on the ventilator casing for 5 seconds, until the beep and blinking of all the LED lights. The ventilator continues in this mode for 3 minutes and then automatically revert to the previous settings. To exit the Setup mode immediately once again press and hold the **Ventilation**  button on the ventilator casing for 5 seconds, until the beep and shutdown of all the LED lights.


In this mode the following settings are available:

- **Wi-Fi network name:** Setup mode.
- **Wi-Fi password:** 11111111.
- **The unit password cannot be read.**

BATTERY REPLACEMENT

The **Alarm** indicator on the ventilator casing blinks, when the battery charge is low. The mobile app will also display the , warning and show the following message on pressing the indicator icon. Low battery power may cause disruptions in the weekly schedule operation. Power off the unit before replacing the battery. After replacing the battery re-set the time and date. The battery is located on the control circuit board. Power off the ventilator to replace the battery, remove the front panel and the cover protecting the control circuit board. Remove the battery and install the new one.

Battery type: CR1220.




CLLOUD SERVER CONNECTION

The ventilators can be controlled using the mobile app via a cloud server connection. This functions enables control of a single or multiple ventilators connected according to Diagram 2 over any distance using the mobile app connected to the Internet.

By default the Control via cloud server function is disabled. To enable the function:


1. Enter the app menu.
2. Select **Connection - At home**.
3. Select the desired ventilator connection.
4. Enter the connection settings menu.
5. Enable **Control via cloud server**.




Note: With this function enabled any loss of Internet connection provided by the home server may result in temporary loss of communication with the ventilator.

To control the master ventilator, create a new account during the first connection through the cloud server. Re-use the account for all further connection. Open the mobile app and go to **Menu-Connection-Through cloud server**:

1. Press the **Add new account** button.
2. Enter a login, a password and an e-mail address for password recovery. Then press the Apply button.
3. The app will log into the account automatically. Add a new master ventilator.
4. To exit the account, press the respective button (if necessary).
5. Enter a ventilator name on your choice, the ventilator ID as stated on the casing under the front panel of the ventilator and the unit password (1111 by default).
6. Confirm the entries.




To log into the account via the mobile app, go to **Menu-Connection-Through the cloud server**.

Then enter the login and password and press the Enter  button.

TECHNICAL MAINTENANCE


Maintenance of the ventilator means regular cleaning of the ventilator surfaces of dust and cleaning and replacement of the filters. To enable access to the main serviced units follow the procedure described below. Turn off the ventilator from power supply with the help of the automatic circuit breaker or the cut-out switch before.

1. Press the lower lug to take off the front panel of the indoor unit. Make sure the thermal actuator rod is in lower position when installing the front panel again. If the thermal actuator rod is up, please wait for about 2 minutes until it goes down.
2. Disconnect the connector from the control circuit board. While removing the connector do not pull the cable. Uplift it with a flat screwdriver of a respective size.
3. Remove the cartridge from the air duct.
4. Remove the filters from the cartridge for cleaning.
5. After cleaning of the filters reassemble the ventilator in the reverse order.




Clean the filters as required, but not less than once in three months.

- In 90 days of non-stop operation the filter replacement indicator (Filter) starts glowing. Reset the filter timer using the mobile application.
- Wash and let the filters dry out completely. Install the dry filters in the air duct.
- Vacuum cleaning is allowed.
- The filter rated service life is 3 years.



Even regular technical maintenance may not completely prevent dirt accumulation on the regenerator and the fan.

- Clean the regenerator regularly to ensure its high regeneration efficiency.
- Clean the regenerator with a vacuum cleaner not less than once a year.



FAILURES AND TROUBLESHOOTING

Failure	Possible reasons	Troubleshooting
The fan does not get started during turning on.	No power supply	Make sure the power supply line is connected correct, otherwise eliminate the connection error.
	The motor is jammed, the impeller blades are contaminated.	Turn the ventilator off. Troubleshoot the motor jam and the impeller clogging. Clean the blades. Turn the ventilator on.
Circuit breaker tripping during turning of the ventilator on.	Overcurrent as a result of a short circuit in the electric circuit.	Turn the ventilator off. Contact the Seller for further information.
Low air flow.	Low set fan speed.	Set the higher speed.
	The filters, the fan or the regenerator are contaminated.	Clean or replace the filter. Clean the fan and the regenerator.
Noise, vibration.	The impeller is contaminated.	Clean the impeller.
	Loose screw connection in the ventilator casing or in the outer ventilation hood.	Tighten the screws of the ventilator or the outer ventilation hood.

STORAGE AND TRANSPORTATION REGULATIONS

- Store the unit in the manufacturer's original packaging box in a dry closed ventilated premise with temperature range from +5 °C to +40 °C and relative humidity up to 70 %.
- Storage environment must not contain aggressive vapors and chemical mixtures provoking corrosion, insulation, and sealing deformation.
- Use suitable hoist machinery for handling and storage operations to prevent possible damage to the unit.
- Follow the handling requirements applicable for the particular type of cargo.
- The unit can be carried in the original packaging by any mode of transport provided proper protection against precipitation and mechanical damage. The unit must be transported only in the working position.
- Avoid sharp blows, scratches, or rough handling during loading and unloading.
- Prior to the initial power-up after transportation at low temperatures, allow the unit to warm up at operating temperature for at least 3-4 hours.

MANUFACTURER'S WARRANTY

The product is in compliance with EU norms and standards on low voltage guidelines and electromagnetic compatibility. We hereby declare that the product complies with the provisions of Electromagnetic Compatibility (EMC) Directive 2014/30/EU of the European Parliament and of the Council, Low Voltage Directive (LVD) 2014/35/EU of the European Parliament and of the Council and CE-marking Council Directive 93/68/EEC. This certificate is issued following test carried out on samples of the product referred to above.

The manufacturer hereby warrants normal operation of the unit for 24 months after the retail sale date provided the user's observance of the transportation, storage, installation, and operation regulations. Should any malfunctions occur in the course of the unit operation through the Manufacturer's fault during the guaranteed period of operation, the user is entitled to get all the faults eliminated by the manufacturer by means of warranty repair at the factory free of charge. The warranty repair includes work specific to elimination of faults in the unit operation to ensure its intended use by the user within the guaranteed period of operation. The faults are eliminated by means of replacement or repair of the unit components or a specific part of such unit component.

The warranty repair does not include:

- routine technical maintenance
- unit installation/dismantling
- unit setup

To benefit from warranty repair, the user must provide the unit, the user's manual with the purchase date stamp, and the payment paperwork certifying the purchase. The unit model must comply with the one stated in the user's manual. Contact the Seller for warranty service.

The manufacturer's warranty does not apply to the following cases:

- User's failure to submit the unit with the entire delivery package as stated in the user's manual including submission with missing component parts previously dismantled by the user.
- Mismatch of the unit model and the brand name with the information stated on the unit packaging and in the user's manual.
- User's failure to ensure timely technical maintenance of the unit.
- External damage to the unit casing (excluding external modifications as required for installation) and internal components caused by the user.
- Redesign or engineering changes to the unit.
- Replacement and use of any assemblies, parts and components not approved by the manufacturer.
- Unit misuse.
- Violation of the unit installation regulations by the user.
- Violation of the unit control regulations by the user.
- Unit connection to power mains with a voltage different from the one stated in the user's manual.
- Unit breakdown due to voltage surges in power mains.
- Discretionary repair of the unit by the user.
- Unit repair by any persons without the manufacturer's authorization.
- Expiration of the unit warranty period.
- Violation of the unit transportation regulations by the user.
- Violation of the unit storage regulations by the user.
- Wrongful actions against the unit committed by third parties.
- Unit breakdown due to circumstances of insuperable force (fire, flood, earthquake, war, hostilities of any kind, blockades).
- Missing seals if provided by the user's manual.
- Failure to submit the user's manual with the unit purchase date stamp.
- Missing payment paperwork certifying the unit purchase.



FOLLOWING THE REGULATIONS STIPULATED HEREIN WILL ENSURE A LONG AND TROUBLE-FREE OPERATION OF THE UNIT.




USER'S WARRANTY CLAIMS SHALL BE SUBJECT TO REVIEW ONLY UPON PRESENTATION OF THE UNIT, THE PAYMENT DOCUMENT AND THE USER'S MANUAL WITH THE PURCHASE DATE STAMP.

CERTIFICATE OF ACCEPTANCE

Unit Type	Single-room reversible energy regeneration ventilator
Model	Vento Expert A30 _____
Serial Number	
Manufacture Date	
Quality Inspector's Stamp	

SELLER INFORMATION


Seller	
Address	
Phone Number	
E-mail	
Purchase Date	
This is to certify acceptance of the complete unit delivery with the user's manual. The warranty terms are acknowledged and accepted.	
Customer's Signature	



Seller's Stamp

INSTALLATION CERTIFICATE


The Vento Expert A30 _____ unit is installed pursuant to the requirements stated in the present user's manual.	
Company name	
Address	
Phone Number	
Installation Technician's Full Name	
Installation Date:	Signature:
The unit has been installed in accordance with the provisions of all the applicable local and national construction, electrical and technical codes and standards. The unit operates normally as intended by the manufacturer.	
Signature:	



Installation Stamp

WARRANTY CARD

Unit Type	Single-room reversible energy regeneration ventilator
Model	Vento Expert A30 _____
Serial Number	
Manufacture Date	
Purchase Date	
Warranty Period	
Seller	



Seller's Stamp



BLAUBERG
Ventilatoren



www.blaubergventilatoren.de
B133-5EN-03

